



PN# 10827: 4-Step Aluminum Ladder Mounting to Low-Pro Dock Frame



Disclaimer:

When mounting ladder ensure Deck Panel is securely attached to dock frame.

Tools Required:

Cordless drill with 3/8" drill bit, pliers, and wrenches

Assembly Hardware:

- (2) Bolt, Nut and Washer 3/8" x 3.5
- (2) Bolt, Nut and Washer 1/4" x 3
- (1) Flat Backer Plate



Step #1: Bolt Ladder to Frame

Locate one pre-drilled 3/8" hole on the frame and temporarily fasten ladder using 3-1/2 bolt assembly. Mark the hole location on the opposite side of the ladder. Remove ladder and drill 3/8" hole. Mount the ladder using the (2) 3/8" x 3-1/2" bolts and nuts. Do not tighten.

Step #2 :Bolt Ladder through Decking

Insert the (2) 1/4" x 3" bolts, through the pre-drilled hole on the shepherd handles resting on the decking. If possible, fit bolts between the decking boards. Secure in place below the deck panel using the aluminum backer plate and nylock nuts. Note: If necessary, drill holes in decking.

